

ROCKA: HOW TO

[INFO](#) | [GALLERY](#) | [TECH](#) | [HOW TO](#) | [AVAILABLE](#)

THIS DOCUMENT IS ALSO AVAILABLE AS A DOWNLOADABLE/PRINTABLE PDF.
TO DOWNLOAD - LOAD THE **ROCKA HOW TO PDF** THEN CHOOSE FILE—>SAVE PAGE AS.

PICKUP SELECTION SWITCH



BRIDGE POSITION = BACK PICKUP.



MIDDLE POSITION = BOTH PICKUPS.



NECK POSITION = FRONT PICKUP.

SINGLE COIL TAP



TO SINGLE COIL TAP THE
HUMBUCKER "PULL UP"

USING THE SPERZEL TUNER



TO INSERT A STRING, TURN THE THUMB WHEEL COUNTER-
CLOCKWISE JUST A FEW FULL TURNS TO LOOSEN UP THE
MECHANISM. FYI - IF YOU TURN IT TO MUCH, THE WHEEL WILL
COME OFF AND A PIN WILL FALL OUT. IF SO, SIMPLY REPLACE
THE PIN AND THEN THE WHEEL.

GUITAR PICKUP HEIGHT ADJUSTMENT



ADJUSTING ON THE PICKUP

TAKE YOUR SUPPLIED 5/32 ALLEN DRIVER
TURN THE CENTER BUTTON HEAD SOCKET CLOCKWISE TO RAISE
THE PICKUP

ADJUSTING ON THE PICKGUARD

TAKE YOUR SUPPLIED 5/32 ALLEN DRIVER
TURN THE CENTER BUTTON HEAD SCOKET CLOCKWISE TO RAISE



THE PICKUP

TO ADJUST THE TRUSS ROD SYSTEM

IT'S UNLIKELY YOU WILL NEED TO ADJUST YOUR TRUSS ROD, AS IT IS SET AT THE WORKSHOP AND CAN STAY LOCKED IN FOR YEARS TO COME. ON OCCASION DURING GLOBAL SHIPPING FROM ONE CLIMATE TO ANOTHER THE NECK MAY MOVE ON ITS OWN DUE TO MOTHER NATURE. IF SHE DECIDES TO MOVE THE WATER MOLECULES AROUND IN THE WOOD SIMPLY FOLLOW THESE SIMPLE STEPS TO ACCOMMODATE HER.

1. TAKE A #3 FAT TIP PHILLIPS SCREW DRIVER (NOT INCLUDED) AND UNSCREW THE CENTER PLUG. THIS IS JUST A COVER FOR THE HOLE.
2. DO NOT TOUCH THE OTHER 4 SCREWS, THEY ARE THERE TO KEEP THE NECK ON.
3. PLACE YOUR SCREWS FAR TO THE SIDE.

TAKE YOUR 5/32 ALLEN DRIVER FROM YOUR SUPPLIED TOOL KIT.

4. WITH SOME GOOD LIGHT TAKE A PEAK INTO THE HOLE AND YOU WILL SEE AN ALLEN HEAD SCREW ABOUT 1 INCH DEEP.
5. INSERT YOUR DRIVER INTO THE HOLE CAREFULLY AND PUT A LITTLE FORCE ON IT AS YOU ARE WIGGLING THE DRIVER SO THAT YOU CAN FEEL IT SLIP INTO THE ALLEN HEAD. YOU'LL KNOW WHEN IT SLIPS IT.
6. DO NOT TURN THE DRIVER MORE THAN 1 FULL TURN FROM ITS NATURAL POSITION.
7. FORWARD BOW TURN CLOCK WISE
8. BACKWARD BOW TURN COUNTER CLOCK WISE
9. NECK ADJUSTMENTS MUST BE DONE WHILE THE INSTRUMENT IS UNDER STRING TENSION AND IN TUNE.
10. YOU MAY HAVE TO WIGGLE THE DRIVE A LITTLE WHEN PULLING IT OUT OF THE HOLE.
11. RE INSERT YOUR #3 PHILLIPS SCREW PLUG AND ONLY TIGHTEN SNUG. DO NOT OVER TIGHTEN TO PREVENT CRACKING THE PAINT AROUND THE COUNTERSINK HOLE.



STEP #1
UNSCREW THE CENTER PLUG



STEP #2
REMOVE CENTER PLUG



STEP #3
CAREFULLY INSERT DRIVER THEN PUSH DOWN A LITTLE AND FEEL IT LOCK IN

HOW THE 'STRESS FREE' TRUSS IS ASSEMBLED



THIS IS A LOOK AT THE "STRESS FREE" TRUSS BAR AND THE SOLID BELL BRASS NUT MOUNT.

THE TRUSS BAR IS EPOXIED INTO THE HEADSTOCK TO ABSORB STRING TENSION.



TRUSS BAR AND HEADSTOCK SEPARATE FROM THE NECK AND NUT MOUNT.



WHAT IS THAT HOLE DOING IN THE NECK?



THIS IS THE PIN HOLE AND IS **AN ESSENTIAL** PART OF THE NECK ASSEMBLY. THIS HOLE HAS **NO** USER FUNCTION AND SHOULD NOT BE TOUCHED.

COPYRIGHT © 2010 HENMAN GUITARS LLC. ALL RIGHTS RESERVED.
SITE BUILT BY **COLOR:GRAY**

